

STEP BY STEP INSTALLATION INSTRUCTIONS

1: CLEAN EXTERIOR WINDOW FRAME with mild soap and water or rubbing alcohol to prepare the surface. Allow to dry.

2. TEST POSITIONING OF SHIELD →

Position on exterior of window frame over the operable panel (s)
Pass thru opening at the bottom should be approximately 12—15”h depending on your window.



Shield for Single Panel Sliders (275/600) is positioned over the operable panel and attaches on top and sides

3. REMOVE BACKING OF DOUBLESIDED TAPE



Shield for Bump Out 10 Window installs beneath lip on exterior



4. PRESS FIRMLY INTO PLACE AROUND SIDES AND TOP OF SHIELD FRAME

Do not reposition.

Tape is very strong and is designed for one application.

TO REMOVE

This is intended as a temporary solution. Designed to be removed without harming the integrity of the window.

Shield can be removed by carefully running a utility knife between shield and window frame. Remove adhesive residue with solvent or rubbing alcohol.

Clean with mild soap and water—no abrasive cloth, paper or chemicals