

### Air Curtain Mounting Position



### Mounting Information:

Mount DTU-3 on inside of building over operable panel of window, or centered over biparting window. Brackets supplied with unit.

**DO NOT** mount to header of window or frame as this may interfere with the operating system of the window or crack the glass.  
(mounting to frame voids warranty of window)

### Electric Information:

Unit supplied with cord and plug

If window is fully electric, ensure air curtain is on separate circuit

FOR BERNER SUPPORT: 800.245.4455

Berner Drive-Thru Units have a one-year (1-year) limited warranty from the original date of shipment. Limited Warranty: Berner International warrants all new air curtains to be free of defects in workmanship and material. Claims will be honored for equipment that has been properly cared for, installed and operated. Warranty excludes any labor charges.