

4

3

2


1

B

B


A

A



RELAY KIT FOR MANUAL OPEN SELF CLOSE DRIVE THROUGH WINDOW  
FOR USE WITH READY ACCESS RAC-22 AND RAC-22-E AIR CURTAINS

- INCLUDES:
1. RELAY FOR USE WITH MANUAL OPEN SELF CLOSE WINDOW
  2. JUNCTION BOX PREWIRED WITH RELAY AIR CURTAIN POWER CORD AND RELAY CONTROL CABLE.
  3. POWER CORD FOR AIR CURTAIN
  4. CONTROL CABLE
  5. MOUNTING SCREWS
  6. WINDOW, AIR CURTAIN AIR CURTAIN MOUNTING BRACKET AND AIR CURTAIN ARE NOT INCLUDED


	NAME	DATE			
DRAWN	BCG				
CHECKED					
ENG APPR.	BCG		TITLE: WIRING DIAGRAM SC WINDOW RAC22 RELAY		
MFG APPR.					
Q.A.					
			SIZE <b>B</b>	DWG. NO.	REV <b>A</b>
SCALE: 1:4			WEIGHT:	SHEET 1 OF 3	

4

3

2

1



4


3

2

1

# RAC-22, MANUAL OPEN SELF CLOSE WINDOW


RELAY



CONNECT TO DOOR SWITCH

MANUAL OPEN SELF CLOSE WINDOW


CONNECTION FROM  
RELAY CONTROL CABLE



DOOR SWITCH

AIR CURTAIN

DOOR SWITCH

	NAME	DATE			
DRAWN	BCG		TITLE:  WIRING DIAGRAM SC WINDOW RAC22 RELAY		
CHECKED					
ENG APPR.	BCG				
MFG APPR.					
Q.A.					
			SIZE <b>B</b>	DWG. NO.	REV <b>A</b>
			SCALE: 1:16	WEIGHT:	SHEET 3 OF 3

4

3

2

1

B

A