



RELAY KIT FOR ELECTRICALLY OPERATED DRIVE THROUGH WINDOW
FOR USE WITH READY ACCESS RAC-22 AND RAC-22-E AIR CURTAINS
INCLUDES:
1. RELAY FOR CONNECTION TO READY ACCESS ELECTRIC CONTROL BOARD OR MOER BOARD
2. JUNCTION BOX PREWIRED WITH RELAY AIR CURTAIN POWER CORD AND RELAY CONTROL CABLE.
3. POWER CORD FOR AIR CURTAIN
4. CONTROL CABLE
5. MOUNTING SCREWS
6. WINDOW, AIR CURTAIN MOUNTING BRACKET AND AIR CURTAIN ARE NOT INCLUDED

	NAME	DATE	TITLE: WIRING DIAGRAM ELECTRIC WINDOW RAC22 RELAY		
DRAWN	BCG				
CHECKED					
ENG APPR.	BCG				
MFG APPR.					
Q.A.					
			SIZE B	DWG. NO.	REV A
			SCALE: 1:4	WEIGHT:	SHEET 1 OF 4

RAC-22, ELECTRIC WINDOW RELAY CONNECTIONS



RAC-22, WINDOW RELAY MOUNTING



MANUAL OPEN ELECTRIC CLOSE

	NAME	DATE	TITLE: WIRING DIAGRAM ELECTRIC WINDOW RAC22 RELAY		
DRAWN	BCG				
CHECKED					
ENG APPR.	BCG				
MFG APPR.					
Q.A.					
			SIZE	DWG. NO.	REV
			B		A
			SCALE: 1:16	WEIGHT:	SHEET 3 OF 4


4

3

2

1

RAC-22, ELECTRIC WINDOW RELAY MOUNTING




B

B

A

A

	NAME	DATE			
DRAWN	BCG		TITLE: WIRING DIAGRAM ELECTRIC WINDOW RAC22 RELAY		
CHECKED					
ENG APPR.	BCG				
MFG APPR.					
Q.A.					
			SIZE B	DWG. NO.	REV A
			SCALE: 1:16	WEIGHT:	SHEET 4 OF 4

4

3

2

1